

Mural Print Installation Manual

Congratulations!

Your decoration will look great with your new self-adhesive wall mural print. You have only a few steps to complete installation.

Recommendations

The wall mural can be installed on a wide variety of smooth surfaces such as gypsum boards, wood, glass, metal and some plastics panels.

However, it does not stick well to textured surfaces. Do not use on too textured paint, concrete or brick. Perform a test on a small area before proceeding with the installation.

The installation surface must be clean, smooth, dry, in good condition and free of moisture, grease and stains.

Remove the peeling paint or old wall coverings prior to installation.

Wait at least 30 days before applying the wall mural on a freshly painted wall.

Installation

1. Roll the first panel so that the printed side is facing inward.
2. Peel off a strip of 6" at the top of the Panel and cut off the excess of the protective paper.
3. Carefully align the side panel with the line previously drawn and apply on the wall.
4. To minimize deformations, always apply the wall mural with a minimum of tension. Slowly unroll the panel to the floor. Remove the protective paper from a few feet. Do not remove much at one time. Smooth the wall mural using a plastic scraper by performing movements from the center to the ends of the panel. Make sure it is straight and free of air bubble.
5. If necessary, carefully remove the panel to release stubborn air bubbles or folds or use anything sharp (needle, tip of a knife) to pierce the surface and smooth with the scraper.

Reminder: Apply a good amount of pressure to insure adherence, especially on the edges of each panel

6. Install the following panels using the same method as above. Panel joints should overlap at about 0.5" . Align the image or pattern with the previous panel. Make sure that the ground is perfectly aligned to the eye. A small difference near the floor seems a lot less once the installation is completed.
7. Once all the panels are installed, cut off the excess from the ceiling and the floor with a utility knife

Tools required

· Utility knife · Smoother, plastic scraper · Level · Lead pencil

Preparation

Use a damp cloth to clean dirt or dust from the surface, and let dry completely before installation.

Remove all panels with caution from the package. Check the order and direction and lay them down on the floor in the room a few hours prior to installation.

Check that the sizes of the wall mural correspond to the height and width of the surface to be covered. Do not cut off the excess non-print on top and at the bottom of the panels as this will help to reduce the handling of the adhesive. **WARNING:** Most floors and ceilings do not form a perfect right angle to the wall; take into account before measuring.

Determine the starting panel. For small surfaces, you can proceed from right to left or left to right. However, if the surface is very high (10 ft +), we recommend to start with the center panel. Using a level, draw a vertical line with a lead pencil. This line will guide the installation of the first panel.